RA OPTION WIRING INSTRUCTIONS

Switch Box and Romex connector (Supplied by others)

2-wire fire alarm cable or equivalent

Recommended maximum run 1000' (Supplied by others)

CENTRAL EMERGENCY LIGHTING SYSTEM

IF ACTIVATED INSPECT SYSTEM

Go2Power A250190 Modular Options PCB

Spare   RA   Fault Sum.

£md NO GND NO NC £.

Jumper For 5V Dry Contacts

NO NC £.   NO NC £.

Relay #1   Relay #2

The RA option is polarity-sensitive. Connect the red wire from the RA panel to the NO terminal on the options board and the black wire to the GND terminal, both located under the RA terminals.