# RA OPTION WIRING INSTRUCTIONS

Switch Box and Romex connector (Supplied by others)

2-wire fire alarm cable or equivalent

Recommended maximum run 1000' (Supplied by others)

CENTRAL EMERGENCY LIGHTING SYSTEM

IF ACTIVATED INSPECT SYSTEM

The RA option is polarity-sensitive. Connect the red wire from the RA panel to the NO terminal on the options board and the black wire to the GND terminal, both located under the RA terminals.

Go2Power A250190 Modular Options PCB

Spare   RA   Fault   Sum.

Cmd   NO   GND   NO   NC   C.

Jumper For 5V Dry Contacts

NO   NC   C.   NO   NC   C.

Relay #1   Relay #2